



*The Aw Naw switch should be wired in series before either of the main gas valves (X9-01.3 or X9-01.4). Engaging the switch will open the circuit and power off the main gas valve. The bypass switch in the DOWN position bypasses the Aw Naw switch entirely. In the UP position, power is run through the Aw Naw switch and can be controlled via the remote shutoff in the dashboard.

Author:
Date:

File:
Folio: 1/1